ICELANDIC - FLUTED





Installation Instructions No Grout

To install these fluted décor tiles, it is recommended to install them butt-tight without the use of spacers or grout joints. Please keep in mind that the tiles may have slight dimensional variances. For this reason, it is essential to conduct a "pre-installation" dry lay to make any necessary adjustments before the actual installation process. Whether or not to use the "End" to complete the installation is up to personal preference - it is not required for a successful installation.

Mortar

Use a premium high-performing latex modified thinset with non-sag characteristics for best results. Do not use Organic Type 1 Adhesives.

Installation Instructions With Grout

Joint Spacing

For best results, it is recommended that the tiles are installed with 1/16" joints to accommodate slight dimensional variances.

Pre-Installation

Conduct a dry lay on a flat substrate to make any necessary adjustments or modifications before the actual installation process.

Mortar

Use a premium high-performing latex modified thinset with non-sag characteristics for best results. Do not use Organic Type 1 Adhesives.

Proper Bedding

Pack and fill the mortar to 100% coverage as not to leave any voids or hollow spots. Due to the tile's unique convex backing, 100% mortar coverage is required. When packing the backside of the tile, utilize the standard back-buttering technique with the flat side of the trowel. Once fully packed, the filled mortar shall be flat, smooth and flush with the edges of the tile.

Grout

For best results, avoid sanded grouts. We recommend unsanded cementitious grouts or single component modified grouts.

ICELANDIC - FLUTED





Disclaimers

- 1. Due to the shape of this product, exposure to water/moisture should be limited.
- 2. Due to the shape of this product, drilling holes should be limited to the flat portion of the tile. Not the curled edges.

Fluted 4"x12"x20mm Matte | Ceramic





