



Pre-Installation Instructions

Conduct a dry lay on a flat substrate to make any necessary adjustments or modifications before the actual installation process.

Mortar

Use a premium, high-performing, latex modified thinset with non-sag characteristics for best results. Do **not** use Organic Type 1 Adhesives

Joint Spacing

For best results, it is recommended that the tiles are installed with 1/16" joints to accommodate slight dimensional variances.

Proper Bedding

Pack and fill the mortar to 100% coverage as not to leave any voids or hollow spots. Due to the tile's unique convex backing, 100% mortar coverage is required.

- When packing the backside of the tile, utilize the standard back-buttering technique with the flat side of the trowel. Once fully packed, the filled mortar shall be flat, smooth and flush with the edges of the tile.

Grout

For best results, avoid sanded grouts. We recommend unsanded cementitious grouts or single component modified grouts.

- Grouting the joints is **not** mandatory.

